

- For the following steps, please prepare:
- Z-axis motor (2x)
- Note each Z-axis motor has different cable length. The shorter one must be on the left side, longer on the right side.
- Z-screw-cover (2x)
- Remove the trapezoidal nuts from the motors. **DON'T THROW** them away, you will need them!
 - The **new kit units no longer have trapezoidal nuts on the motor rods**. They are included inside the motor kit box.
- Screw the Z-screw covers onto both leadscrews.
- Covers should be screwed fully to the motor, but not too tight! The motor must be able to spin freely!

