

- **ATTENTION**: be very careful during the tightening, check the nut orientation and **DO NOT** use excessive force, you can break this part.
- Insert the M3nN nyloc nut in the X-end-idler.
- In case you can't press the nut in, **don't use excessive force**. Leave the nut for now and proceed with the other components for this step.
- Insert the 623h bearing into the X-end idler.
- Secure it in place using an M3x18 screw.
- (i) Now, if needed, use the M3 screw to pull the nut in.
- Place your finger on the bearing and ensure it can rotate freely. If needed adjust the screw.

